

# Arrival Checklist

- ☐ 1. Never backup rig without safety observer with radio or standard hand signals.
- ☐ 2. At check in, decide where site is, how to get to it, and whether the Bikes need to be unloaded before parking in site.
- ☐ 3. At site do a walk around to check for obstructions and plan where FW needs to be with respect to hookups and slide operation. Confer with safety guard on plan before backing.
- ☐ 4. Pull or back into site with FW positioned correctly for hookups, slide, and tailgate.
- ☐ 5. Level side to side using Spirit Level and appropriate planks and blocks then set truck brakes, and put in park.
- ☐ 6. Chock wheels and install both vise chocks.
- ☐ 7. Lower landing gear(make sure pins are engaged) raising FW 1/8 inch off hitch.
- ☐ 8. Disconnect Electrical lead and breakaway cable from truck.
- ☐ 9. Dump Air Bag truck & Hitch.
- ☐ 10. Verify Landing gear is down, electrical, and breakaway cables are disconnected and tailgate is down "if applicable".
- ☐ 11. Remove safety pin. Pull out Hitch handle till unlocked and stays in the unlocked position.
- ☐ 12. Carefully drive out from under FW.
- ☐ 13. Set Parking brake clear of FW.
- ☐ 14. Level FW fore and aft using Spirit Level and landing gear to raise or lower, or auto level.
- ☐ 15. Extend STABILIZERS.
- ☐ 16. Disconnect battery landing gear lead to de-activate landing gear switch.
- ☐ 17. Lower FW steps and unlock doors.
- ☐ 18. Turn on Propane at tank and allow 5 minutes before lighting gas appliances.
- ☐ 19. Connect to shore power using surge protector/ safety lights. Follow procedure 2min 16sec.
- ☐ 20. Hookup water pressure regulator and filters to FW.
- ☐ 21. Use rubber gloves and connect sewer connection to campground inlet and arrange so will drain properly with supports.

# Arrival Checklist

- ☐ 22. Confirm hot water tank has filled before turning power on (two switches) or LP switch by sink (DSI) if LP is used.
- ☐ 23. Open vent, door, or window and check for obstructions inside and outside prior to extending slide.
- ☐ 24. Extend awning if appropriate anchor and place rugs and mat in place.
- ☐ 25. Unload chairs and other camping gear as needed.
- ☐ 26. Plug in voltmeter and verify in green before starting air conditioner or turning on furnace.
- ☐ 27. Turn on the refrigerator and set in auto or LP if no electricity.
- ☐ 28. Leave water pump off unless not connected to city water.

## TEMPORARY STORAGE BEFORE NEXT TRIP:

- ☐ 1. Remove food and any garbage or trash left from trip.
- ☐ 2. Open refrigerator door and cabinets for ventilation.
- ☐ 3. Place lock on Kingpin.
- ☐ 4. Disconnect battery. Check for correct water level and charge level.
- ☐ 5. Verify LP is off and remove empty tanks to be filled.
- ☐ 6. Lock all storage and main doors.
- ☐ 7. Remove or lock FW hitch in truck.
- ☐ 8. Put on covers (tires, AC, TrailerSaver, etc.)
- ☐ 9. Make list of anything to be repaired or obtained before the next trip.
- ☐ 10. Get things on list completed.

PLEASE ADD -OR- SUBTRACT AS YOU SEE FIT

## INSPECTION NOTES:

---

---

---

---